

P400 Quick Reference

Turning On

Either connect to power or press the button with the green circle \bigcirc for 5 seconds until the screen lights up.

Turning Off

Unplug the power cord and press the button with the red cross 🗱 for 5 seconds until the screen changes and gives you four options. Select Shutdown by touching the screen.

Get out of Verifone Idle Screen

- 1. Press Enter
- 2. Then Press 999 to get off the Verifone Screen and into settings

Purchase

- 3. Enter in the purchase price on the screen and press $ENTER \bigcirc$
- 4. Present customer card
- 5. Customer selects account and enters PIN.

Purchase with Cash

- 1. Press # then select 3, enter the purchase amount then press ENTER
- 2. Enter cash out amount,





- 2. Press ENTER 🔾
- 3. Present customer card,
- 4. Customer selects account and enters PIN.

Log On

Press # on the screen then select Log On.

Settlement

- 1. Touch # on the screen, then # again, select Settlement.
- 2. Touch Cutover and then $ENTER \bigcirc$

Process a Refund

- 1. Press # then # again, select Refund,
- 2. Swipe merchant card then type in the Merchant Pin and press ENTER
- 3. Type in Refund amount and press ENTER \bigcirc
- 4. Customer swipe card,
- 5. Customer enters their account and pin number,
- 6. Transaction complete.

Card Not Present Transaction

- **1.** Type in the purchase amount then press ENTER \bigcirc
- 2. At the Present Card screen start typing the card number then press ENTER
- **3.** Type in Expiry Date then press ENTER
- 4. Select Yes or No to answer CSC number is available,
- 5. Type in the CSC Number and press ENTER \bigcirc
- **6.** If no CSC number available select reason why unavailable, 7. Select Credit, terminal will then process and display the result.

Adding a Surcharge



- 1. Press the # button three times before selecting Option 2 for Setup
- 2. Enter in the Setup Password "999" followed by ENTER 🔘
- 3. Select Option 3 for Surcharge
- 4. If you are wanting a Percentage, select Option 3
- 5. Enter in the minimum surcharge amount followed by ENTER and maximum surcharge amount followed by ENTER O
- 6. Type in the percentage you are wanting, i.e., if you are wanting a 2.5% surcharge, type in 25.00
- 7. Press ENTER again through the minimum and maximum surcharge amount
- 8. Select Option 1 if you want this enabled on Contactless/PayWave transactions or Option 2 if you do not
- 9. Hold down the red cross 🗱 and reboot the terminal

Customer Receipt Options

- 1. Press the # button three times before selecting Option 1 for Utility
- 2. Select Option 2 for Print Utility
- 3. Select Option 1 for Receipt Options
- 4. Select Option 1 if you do not wish to print receipts, Option 2 if you want one receipt printed or Option 3 if you want two receipts to print
- 5. Select Option 1 if you want it to always print out a merchant receipt or Option 2 if you want it to ask before printing a merchant receipt
- 6. Press ENTER 🔘 and reboot the terminal

